

Übersicht: Marshall Fußschalter

Anzahl der Schalter	1						2						3		4			5	6						
Für die Modelle	MR-PEDL00008	MR-PEDL00001	MR-PEDL00034	MR-PEDL00040	MR-PEDL00005	MR-PEDL00009	MR-PEDL00013	MR-PEDL00010	MR-PEDL00004	MR-PEDL00029	MR-PEDL00041	MR-PEDL90010	MR-PEDL-10009	MR-MPM3E	MR-PEDL00014	MR-MPM4E	MR-PEDL00045	MR-PEDL00038	MR-PEDL10049	MR-PEDL90008	MR-PEDL00021	MR-PEDL00039	MR-PEDL00032	MR-PEDL00044	
JVM410H, JVM410C																								✓	
JVM210H, JVM205H, JVM205C, JVM215C, JVM210C																	✓								
2466, 2266, 2266C										✓															
1974X			✓																						
DSL50, DSL100	0	✓ 0																							
DSL401	0	0					✓																		
MHZ40C													✓						0						
MHZ15													✓												
EL34 50/50, EL34 100/100, EL84 20/20	0	0																							
AVT50 (XT), AVT50H (X)		✓																							
AVT100(XT)																		✓							
AVT150(X), AVT150H(XT), AVT275(X)																							✓		
AS50D										0															
AS100D		✓																							
MG15FX, MG30FX, MG15HFX																					0				
MG50FX, MG101FX, MG102FX, MG100HFX												✓									0				
MB30	0																								
MB60, MB150	✓																								
MB4210, MB4410, MB450H					✓																				
EH1				0																					
Ältere Modelle																									
AS50R										0															
DSL201		✓																							
MF350																								✓	
MG50DFX, MG250DFX, MG100DFX, MG100HDFX									✓																
G30RCD	0	0																							
G50RCD, G80RCD, G100RCD	✓																								
JCM600, JCM601, JCM602	✓	0																							
JMP1																0									
JTM612, JTM60, JTM622, JTM610, JTM615	✓	0																							
MG30DFX, JTM312, JTM310	0																								
TSL100, TSL122, TSL60, TSL601, TSL602																						✓			
VS30R	0	0																							
VS65R		✓																							
VS100R, VS100H, VS102R							✓																		
VS230R, VS232R								✓																	
VS265R															✓										
1962	✓																								
2555SL, 2100, 2500	0	0																							
4100, 4500, 4101, 4102, 4501, 4502						0																			
6100, 6101														✓											
7400, 7200, 72115, 72410, 9100, 9200	0	0																							
8040, 3520, 5522	✓																								
8200, 8240, 8280							✓																		
9004	0																								
9080, 8100					✓																				

o = optionales Zubehör (Empfehlung)

✓ = bereits im Lieferumfang enthalten